

Programming your Norstar Keyphone for Headset working

Use the programming overlay below and place it over the relevant keys (indicated in the grey boxes on the overlay) on your M7310 or M7324 programming phone

Select the FEATURE key and use the keypad to type ** 2364623646

Press NEXT 4 times

Press SHOW

Press NEXT 2 times

Press SHOW

Enter the extension number of the telephone you want headset working on

Press NEXT 3 times

Change Full Handsfree to Y (with right hand side button under the display)

Press NEXT

Change Auto Handsfree to Y (with right hand side button under the display)

Press NEXT

Change HF Answerback to Y (with right hand side button under the display)

Press RLS

The selected extension should now be headset working

